


Instructions For Use



IMPORTANT: You must reset the lifting column prior to use.

Reset Procedure:

1. Press and hold the DOWN button on the handset until the column reaches its lowest height.
2. Release the DOWN button.
3. Press and hold the DOWN button for about 5 seconds until the desk slightly rises 5mm, and stops.
4. Release the DOWN button. The desk will be ready to use.

Adjust desk height:

Press UP or DOWN button to adjust the lifting height.

NOTE

Do not attempt to open the housing of the following components

Contact with electrical voltage may cause serious injury and death by electrocution

Do not pull on the power cord to unplug the plug from the power outlet

If any issues, please contact your sales rep.